

## Firmware Upload for Rollei Actioncam 630

### Instructions for uploading the new firmware for the Actioncam 630

- ▶ Save the firmware file "*AC630 Firmware\_Update.zip*" on your computer.
- ▶ Extract the saved file "*AC630 Firmware\_Update.zip*" to your computer.
- ▶ Copy the unpacked "*AC630.BRN*" and "*KEY*" files to a formatted memory card.
- ▶ Fully charge the Actioncam 630 battery before update.
- ▶ Insert the memory card into the off camera.
- ▶ The update will start automatically and the camera will switch itself off after a successful update.

### Attention

Do not remove the battery from the camera during the update and do not remove the memory card. This may result in irreparable damage to the camera and the resulting damage to the device may not be warranted.

- ▶ After update is finished, please remove the memory card, put it in again in your computer and delete the files „*AC630.BRN*“ and "*KEY*" on the memory card. Then the memory card can be used again with Actioncam 630.

### Please note

Please note that the warranty of your camera will expire if it is damaged by improperly performing a firmware upgrade. Therefore, proceed exactly point by point as described in this manual. Of course, you can send your camera to us to update the firmware. Please pay attention to the procedure on the warranty card.