



## **Firmware-Update**

for the actioncams 4s Plus, 5s Plus, 6s Plus,  
8s Plus and 9s Plus

**To install the update on the actioncam you need a compatible microSD card.**

**On the side or on the downside of the camera under the battery compartement cover you can find the microSD card slot.**

1. Connect the microSD card with a card reader to the PC and copy the firmware update file (.img or .BRN) to the memory card.
2. Disconnect the memory card from the PC and insert it into the camera.
3. Turn on your camera and confirm the firmware update.
  - a. For the 4s Plus and 5s Plus select "Confirm" with the Up or Down Button and confirm with the Shutter Button.
  - b. For the 8s Plus and 9s Plus select "Yes" with the Power Button and confirm with the Shutter Button.
4. After the update is complete, format the microSD card in the actioncam.