



Firmware Update

for the Soluna LED continuous lights

To install the update on the Soluna, please remove the power supply first.

On the front side of the Soluna control box is the USB-C port.

1. Connect the control box of the Soluna to the PC or Mac via USB.
After PC and LED light are connected, Soluna appears as removable disk.
2. Copy the firmware file (.bin) to the removable disk.
3. Disconnect the Soluna from the PC by simply disconnecting the USB cable, do not eject the disk!
4. Connect the Soluna to the power supply and turn the device on.