



# **Firmware Update**

## for the studio flash Rollei HS Freeze 4

**To install the update on HS Freeze 4, please remove the battery first.**

**On the back of the flash is the mini-USB port.**

1. Connect the HS Freeze 4 to the PC or Mac via USB.  
After PC and flash are connected, HS Freeze appears as removable disk.
2. Copy the firmware file (.bin) to the removable disk.
3. Disconnect the HS Freeze 4 from the PC by simply disconnecting the USB cable, do not eject the disk!
4. Insert a charged battery into the flash and turn the device on.