

Eco-Friendly Photo Bags for Small, Medium or Large Equipment

- Perfect for photography equipment, applicable for travel and adventure of all kinds
- Compatible with the Fotoliner Ocean Adventure
- Flexible main pocket with adjustable dividers and elastic straps for stability
- Carrying handles and shoulder strap for comfortable carrying
- Eco-friendly thanks to material made from 6, 7 or 8 recycled plastic bottles



Equipment not included.

Technical Data

Type	Photo bag
Dimensions outside	S: Ca. 31 x 19 x 20 cm M: Ca. 32 x 22 x 20 cm L: Ca. 32 x 29 x 20 cm
Dimensions Volume main pocket	S: Ca. 25 x 14 x 18 cm Ca. 6 l M: Ca. 27 x 18 x 18 cm Ca. 9 l L: Ca. 27 x 25 x 18 cm Ca. 12 l
Length shoulder strap	Minimum: Ca. 78 cm Maximum: Ca. 145 cm
Additional features	Flexible adjustable dividers, elastic straps, mesh pocket, carrying handles, shoulder strap, storage bag
Material	RPET (polyester from recycled plastic), polyester, plastic
Weight	S: Ca. 770 g M: Ca. 866 g L: Ca. 1,086 kg

What's in the Box and Packaging Details

What's in the box	1x cube, 1x shoulder strap, 1x storage bag
Packaging dimensions Weight	S: Ca. 29 x 21 x 17 cm Ca. 1.046 kg M: Ca. 29 x 21 x 21 cm Ca. 1.157 kg L: Ca. 29 x 27 x 21 cm Ca. 1.399 kg

Specifications are subject to change without notice.

Item No.: 20341



Item No.: 20342



Item No.: 20343

