

## Radio Transmitter For Triggering Off-brand Clip-on Flashes

- Multicompatible hot shoe connector: For Canon, Nikon, Fuji, Panasonic, Olympus and Sony\*
- Extra hot-shoe adapter: For triggering off-brand clip-on flashes
- Effortless integration: Compatible with all Freeze and studio flashes
- Multiple modes: Manual, TTL and HSS, depending on flash support
- Power supply: Powered by standard AA batteries



### Technical Data

<b>Compatibility</b>	Canon, Nikon, Fuji, Panasonic, Olympus and Sony*
<b>Frequency</b>	2.4 GHz
<b>Operating range</b>	> 100 m
<b>Channels   Groups</b>	31   6
<b>Flash modes</b>	TTL / Manual
<b>Sync modes</b>	HSS / Freeze / 1st / 2nd shutter curtain
<b>Synchronisation time</b>	Canon/Sony/Fuji/Panasonic/Olympus: 1/250 s or less, Nikon: 1/320 s or less
<b>Radio frequency band</b>	2.402 – 2.480 GHz
<b>Transmission power maximum</b>	6 dBm
<b>Dimensions (L x W x H)   Weight</b>	7.2 x 6.8 x 5.3 cm   100 g

### What's in the Box and Packaging Details

<b>What's in the box</b>	Professional radio transmitter TR-Q6II, manual
<b>Packaging dimensions (L x W x H)   Weight</b>	14.5 x 12 x 5 cm   171 g

Specifications are subject to change without notice. \*Only with separately available adapter.

