

3 axes gimbal for actioncams with integrated power bank

- ▶ For smooth videos that are filmed by hand with your Actioncam
- ▶ Stabilizing on all 3 axes and 640° panning
- ▶ 4 working modes (pan, pan/pich, lock & all follow mode)
- ▶ Operation via integrated joystick – 4 functions (up, down, right and left)
- ▶ Light and compact structure
- ▶ Free smartphone app for iOS and Android for remote control of the gimbal

Integrated power bank with 4000 mAh

- ▶ Mobile charging for actioncams or smartphones



Technical Data

Axes	Pan axis: 640° Roll axis: 320° Pitch axis: 320°
Suitable for	GoPro®* Hero®* 7 / 6 / 5 / 4 and 3 as well as other actioncams in similar size (BxHxW up to 62.5 x 45.8 x 24 mm) and in similar weight (max. 75–125 g)
Operating Voltage	3.2 V – 4.0 V
Operating Time	Up to 12 hours
Power Supply	Rechargeable lithium ion battery with 4000 mAh
Size	244 x 76 x 82 mm
Weight	361 g
Scope of Delivery	Gimbal, bag, tripod, USB cable and manual

Subject to technical changes.
Actioncams not included in delivery. *GOPRO® and HERO® are trademarks or registered trademarks of GoPro, Inc. in the United States and / or other countries.