

- ▶ Easy handling
- ▶ Easy-to-read LCD with backlight
- ▶ Timer remote control for: starting time (start of shooting), exposure time, interval timer up to 100 hours in advance
- ▶ Adjustable exposure time between 1 second up to 100 hours
- ▶ Manually controlled exposure with time indication on the LCD
- ▶ Exposure control with additional sound signal
- ▶ Continuous shooting: 1 up to 399 photos
- ▶ Time interval recording with endless shots
- ▶ Incl. batteries



Technical Features

- ▶ Length of connection cable: 120 cm
- ▶ Dimensions: approx. 155 x 40 x 18 mm
- ▶ Weight: approx. 80 g (without batteries)

Compatible Camera Models

Panasonic

DMC-G5, DC-GH5, DC-GH5S, DC-GH5GK, DC-S1R, DC-S1, DC-S1H, DC-S5, DC-GF9K GK, DMC-G85GK, DMC-GX8, DMC-G1, DMC-GF1, DMC-G2, DMC-GH1, DMC-GH2, DMC-GH3, DMC-GH4, DMC-FZ1000, DMC-GX7, DMC-FZ100, DMC-FZ200, DMC-FZ20, DMC-FZ150, DMC-FZ20K, DMC-FZ20S, DMC-FZ30, DMC-FZ30K, DMC-FZ30S, DMC-FZ50K, DMC-FZ50S, DMC-FZ50, LC-1, L1, DIGILUX2, DIGILUX3, L-10, DM-C3, DMC-G10

Scope of Delivery

Rollei Cable Release, adapter cable, AAA batteries, user manual

Subject to technical changes.