

Remote Control Release wireless with 2.4 GHz for Nikon

www.**rollei**.com

- Range up to 50 m
- ▶ Easy handling
- ▶ Easy-to-read LCD with backlight
- ▶ Timer remote control for: starting time (start of shooting), exposure time, intervall timer up to 100 hours in advance
- ▶ Adjustable exposure time between 1 second up to 100 hours
- Manually controlled exposure with time indication on the LCD
- Exposure control with additional sound signal
- ▶ Continuous shooting: 1 up to 399 photos
- ▶ Time interval recording with endless shots









- Length of connection cable (from receiver to camera): 24 cm
- Dimensions: transmitter: approx. 106 x 46 x 27 mm
- Dimensions: receiver: approx. 64 x 38 x 35 mm
- Weight transmitter: approx. 49 g (without batteries)
- Weight receiver: approx. 30 g (without batteries)

| C | | - / | C | B # | 1 - 1 - |
|-----|-------|-----|----------|-------|---------|
| Com | патіп | ДΑ | Camera | IVIOC | 1015 |
| | patib | | carriera | 10100 | |

Nikon

Df, D1, D1H, D1X, D2H, D2HS, D2X, D3, D3S, D3X, D4, D4S, D5, D90, D100, D200, D300, D300S, D500, D600, D610, D700, D750, D800, D800E, D810, D850, D3100, D3200, D3300, D5000, D5100, D5200, D5300, D5600, D7000, D7100, D7200, D7500

Scope of Delivery

Remote transmitter and receiver, adapter cable for receiver, AAA batteries for transmitter, CR2 battery for receiver and user manual

Subject to technical changes.

