

Fly 80 Combo – The quadrocopter for the view from above

- Built-in six-axis gyroscope for stable flight attitude
- Integrated HD camera
- Live image transmission of the drone via WiFi function to your smartphone
- Flight time of approx. 10 to 12 minutes
- 3 speed modes
- Auto hover function
- One-key-return function
- Emergency stop function
- Headless flight mode
- 360° flip possible
- Free app „Fly Air“



Technical Data

Model	Fly 80
Camera Sensor	2 MP
Adjustable Camera Tilt	0 - 60° (manually adjustable)
Video Quality	1920x1080p (25 fps, without sound) on microSD memory card 1280x720p (25fps, without sound) on smartphone
Photo Quality	1920x1080
Flight Mode	Beginner (approx. 10km/h), intermediate (approx. 13 km/h), advanced (approx. 17 km/h)
Control Range	Approx. 30 - 40 m
Range WiFi	30 m (without obstacles or interferences)
Battery	Lithium-Polymer battery 1,200 mAh
Flight Time	Approx. 10 - 12 min.
Charging Time	Approx. 120 min.
Dimensions (L x W x H) Weight	29.5 x 28.7 x 5 cm (unfolded) 14.5 x 9.2 x 5 cm (folded) 155 g (including battery and rotor blades)

What's in the Box and Packaging Details

What's in the box	1x Fly 80, 1x remote control with smartphone holder, 2x batteries, 4x spare rotor blades (incl. screws), USB charging cable, 3x AA batteries, 1x screwdriver, 1x bag, 1x manual
Packaging dimensions (L x W x H) Weight	22.8 x 30 x 10.5 cm 243.4 g

Specifications are subject to change without notice. Other trademarks and trade names are the property of their respective owners.

