

Fotoliner Photo Backpack L

www.rollei.com

Large Photo Backpack with many compartments

- > One main camera compartment on the back side
- ▶ Lateral camera quick access
- Weatherproof zippers
- ▶ Removable waist belt incl. zipper compartment
- Incl. rain cover (underneath the backpack)









Top Details

- Main compartment for the camera on the back side
- Multiple mesh pockets in the main compartment for stowing accessories
- > SD-Card pocket in the main camera compartment
- Compartment on the front side with multiple storage options for accessories
- ▶ Flexible design of the camera compartment
- Tripod mount on the front side
- Diverse mounting options for accessories on the sides and on the carrying strap
- Mesh pocket on the side for carrying water bottles or mounting a tripod
- Adjustable shoulder straps incl. chest strap
- Breathable padding at the back for ideal wearing comfort
- Padded laptop compartment
- Comfortable carry handle
- Rubberized bottom side for quick cleaning
- > Stands on the bottom side of the backpack for better stability

Technical Features	
Material	1680D polyester (outside) / 210D polyester (inside)
Inner dimension	28 x 51.5 x 17 cm
Outer dimension	33 x 56.5 x 22 cm
Weight	1.78 kg
Scope of delivery	Backpack, rain cover

Subject to technical changes.

