

- ▶ Easy handling
- ▶ Easy-to-read LCD with backlight
- ▶ Timer remote control for: starting time (start of shooting), exposure time, interval timer up to 100 hours in advance
- ▶ Adjustable exposure time between 1 second up to 100 hours
- ▶ Manually controlled exposure with time indication on the LCD
- ▶ Exposure control with additional sound signal
- ▶ Continuous shooting: 1 up to 399 photos
- ▶ Time interval recording with endless shots
- ▶ Incl. batteries



Technical Features

- ▶ Length of connection cable: 120 cm
- ▶ Dimensions: approx. 155 x 40 x 18 mm
- ▶ Weight: approx. 80 g (without batteries)

Compatible Camera Models

Fuji

GFX-50, GFX-50S, X-Pro 2, X-Pro3, X30, X70, X100T, X-A1, X-A2, X-A3, X-E1, X-E2, X-E2S, X-E3, X-M1, XQ1, XQ2, X-S1, X-T1, X-T2, X-T3, X-T10, X-T20, X-T30, X-T4, FinePix S1, FinePix S100FS, FinePix S9000, FinePix S9100, FinePix S9500, FinePix S9600, FinePix IS-1, S20, FinePix S205EXR, FinePix S200EXR, FinePix HS20EXR, FinePix HS22EXR, FinePix HS28EXR, FinePix HS25EXR, FinePix HS33EXR, FinePix HS30EXR, FinePix HS35EXR

Scope of Delivery

Rollei Cable Release, adapter cable, AAA batteries, user manual

Subject to technical changes.