

Camera Lens Pen

www.rollei.com



Camera Lens Pen

- ▶ The Rollei camera lens pen with its coated, spherical cleaning edge effectively removes fingerprints, grease spots and dust.
- ▶ The soft nylon brush is used for precleaning of the lenses.

Scope of delivery

1x camera Lens Pen, 1x microfiber cloth (15x15 cm)

Subject to technical changes.



