



# Contents

- Packing list
- Structure
- Application
- APP installation
- Remote controller introduction
- After-Service
- Warranty card

# Packing list

## Packing list



Teleprompter



Smartphone clamp



Smartphone/Tablet clamp



2/55/58/62/67/72/77mm) Lens adapter



Remote controller



Hexagon wrench /Screw



Foam ring




Microfiber cloth



User manual

# Structure


## Structure





# Structure

## Structure





# Application

Using the smartphone for live stream Share below two methods for your reference





#### Installation steps



Take out clamp's components



Install the clamp on the teleprompter



Tighten with the screw cap



Install the teleprompter on the tripod by 1/4" screw hole on the bottom



Inner foam ring, outer foam ring, 49mm lens adapter, paste the outer foam ring on the 49mm lens adapter, and then select the inner foam ring that matches the phone lens and embed it in the center of the outer foam ring



Install the assembled 49mm lens adapter onto the teleprompter



Install the phones in front of and rear of the teleprompter

# Application

# Using DSLR for live stream

Methods 1: Tablet + DSLR



Methods 2: Smartphone + DSLR



# Application

#### Installation steps



Take out the lens adapter



Install the lens adapter on your camera



Install the teleprompter on the camera



Put the teleprmpter's smartphone on the teleprompter



Install the whole teleprompter on the tripod



Adjust the focus of lens to full screen



#### APP installation

# IOS app download



IOS user search"BESTVIEW."

#### Audroid app download





Use your scan tool scan the QC Code to download

#### Remote controller introduction



#### Remote controller


#### Remote use instruction

```
1.power on: Keep press (about 2 seconds).
2.power off: Keep press (about 5 seconds).
```

Notice: if power on without connect anything, it will power off after 5 minutes; if connected the phone, it will power off after 30 minutes

3.Connect: After power on, LED lights on, auto into compare mode, select BESTVIEW T1 toconnect. after connected, LED lights off. Next time it will connect automatically. If you want connect new device. on power off mode, keep press OVEN longer than 8 seconds, lighs flicker, then into the compare mode.





#### Conditions of Warranty Service

- 1.Free service for one year from the day of purchase if the issue is caused by manufacturing errors.
- 2. The components and maintenance service fee will be charged if the period is expired.

Free service will not be provided in the following situations (\* Even if the product is still within the warranty period)

- 1.Damage caused by abuse or misuse, dismantling, or changes to the product not made by the company.
- 2.Damage caused by a natural disaster, abnormal voltage, and environmental factors, etc.

# Warranty card

Warranty Card				
User Infomation				
Name:	Phone:			
Add:				
Sales Infomation				
Sale date:				
Distributor name:				
Distrbutor tel:				
Repair log				
Repair date:	Repair name:			
Issue:				
Result: 🔲 Repaired 🗎 Not repa	ired Return			

