

Radio transmitter for Rollei Studio Flash

- ▶ Easily attached to the camera via the hot shoe
- ▶ Compatible with many common cameras
- ▶ Using of up to 16 channels and 10 groups
- ▶ Supports flash sync times of 1/160s – 1/250s depending on the camera used
- ▶ Radio transmitter with 2.4 GHz



Technical Data

Suitable for	Canon, Nikon, Sony, Fuji, Olympus, Pentax, Panasonic
System mode	2.4 GHz wireless transmitter
Radio distance	300 meters
Channels	16
Groups	10
Flash modes	Manual
Connection	Hot Shoe
Power supply	2x AAA batteries (1.5 V / not included)
Size	78 x 49 x 38 mm
Weight	51 g
Scope of delivery	1 radio transmitter, user manual

Subject to technical changes.